

MS-152-X

Phase rotation indicator

Application:

- Phase rotation indicator activated from 85 V.
- Signaling via the successive lighting of diodes symbolising rotation.
- Works on generating unit.

Features:

- The diodes indicate :
 - clockwise rotation: mark with arrow OK,
 - Anti clockwise rotation indicated by the red arrow "INVERSE"
 - Fault: the DEFECT diode (DEFAUT) indicates an error of connection such as the cut or absence of phase or the presence of neutral between phases

Composition:

- 3 probes IP2X with retractable protector with 1,20 flexible cable.
- 2 crocodile clamps.
- 1 carrying bag with strap.

