



Network Type : LV

<u>n</u>

DT-170..

Installation tester CATEX

Application:

The CATEX testers enable you to perform the following checks:

- Presence of voltage at the terminals of a socket.
- Integrity of the earth circuit.
- Correct polarity. The position of the phase and the neutral is indicated.
- Correct operation of the RCD system at the following sensitivities : 30 mA and 500 mA.
- Enables differential circuit breakers to be tested: 10mA/30mA/300mA and 500mA

The RCD check function is only applicable to single phase circuits: 230 V between phase and neutral.

Features:

- Operating voltage: 230 V \pm 10%.
- Frequency: 50 / 60 Hz ± 10%.
- Operating temperature: 15°C / + 45°C.
- IP 40 IK 03.
- Fuse protection: 2 delayed fuses 250 mA.
- CAT III 600 V

Optionnal accessories:

• <u>M-952271</u> : cord for intervention on LV tables.





Référence	Weight (kg)
DT-170	0,36



